

 FD-143 USB2.0: 15+FLASH (>500)	 FD-144 USB2.0: 13+FLASH (>500)	 FD-145 USB2.0: 12+FLASH (>500)	 FD-146 USB2.0: 15+FLASH (>500)
 FD-139 USB2.0: 13+FLASH (>500)	 FD-140 USB2.0: 12+FLASH (>500)	 FD-141 USB2.0: 15+FLASH (>500)	 FD-142 USB2.0: 13+FLASH (>500)
 FD-134 USB2.0: 17.5+FLASH (>500)	 FD-110 USB2.0: 30+FLASH (>500)	 FD-136 USB2.0: 15+FLASH (>500)	 FD-138 USB2.0: 12+FLASH (>500)
 FD-130 USB2.0: 12+FLASH (>500)	 FD-131 USB2.0: 15+FLASH (>500)	 FD-132 USB2.0: 12+FLASH (>500)	 FD-133 USB2.0: 15+FLASH (>500)

 FD-126 USB2.0: 12+FLASH (>500)	 FD-127 USB2.0: 12+FLASH (>500)	 FD-128 USB2.0: 12+FLASH (>500)	 FD-129 USB2.0: 12+FLASH (>500)
 FD-122 USB2.0: 13+FLASH (>500)	 FD-123 USB2.0: 12+FLASH (>500)	 FD-124 USB2.0: 12+FLASH (>500)	 FD-125 USB2.0: 12+FLASH (>500)
 FD-120 USB2.0: 14+FLASH (>500)	 FD-119 USB2.0: 14+FLASH (>500)	 FD-118 USB2.0: 13+FLASH (>500)	 FD-117 USB2.0: 13+FLASH (>500)
 FD-116 USB2.0: 13+FLASH (>500)	 FD-115 USB2.0: 13+FLASH (>500)	 FD-114 USB2.0: 15+FLASH (>500)	 FD-113 USB2.0: 19+FLASH (>500)
			

FD-108 USB2.0: 12+FLASH (>500)	FD-107 USB2.0: 12+FLASH (>500)	FD-106 USB2.0: 14+FLASH (>500)	FD-105 USB2.0: 15+FLASH (>500)
 FD-104 USB2.0: 13+FLASH (>500)	 FD-103 USB2.0: 14+FLASH (>500)	 FD-102 USB2.0: 20+FLASH (>1k)	 FD-101 USB2.0: 28+FLASH (>1k)

 FD-112 USB1.1: 10+FLASH (>500) USB2.0: 10.5+FLASH (>500)	 FD-111 USB1.1: 10+FLASH (>500) USB2.0: 10.5+FLASH (>500)	 FD-01 USB1.1: 10+FLASH (>500) USB2.0: 10.5+FLASH (>500)	 FD-02 USB1.1: 10+FLASH (>500) USB2.0: 10.5+FLASH (>500)
--	--	--	---